







































































Original	Substituto	Original	Substituto
 Power	 Power	 [...]	 Subt
 Input	 AV	 Red	 Red
 Digital/Analog	 D. Menu	 Green	 Green
 Audio	 Dual	 Yellow	 Yellow
 [+]	 3D	 Blue	 Blue
 Sync Menu	 Menu	 Guide	 Guide
 1	 1	 [i]/[?]	 Info
 2	 2	 Return	 Back
 3	 3	 Options	 Options
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Home	 Smart
 0	 0	 Vol+	 Vol +
 [=]/Text	 Text	 Vol-	 Vol -



