



Original	Substituto
 Power	 Power
 Display	 Shift + Info
 Mute	 Mute
 Video	 Back
 Scart	 Smart
 PC	 Media
 TV	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Substituto
 Subpage	 Eject
 PRE-CH	 Pre Ch
 Source	 AV
 PIP	 3D
 Sound	 Dual
 Sleep	 Sleep
 DTV Menu	 D. Menu
 Zoom-	 <<
 Zoom+	 >>
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down



