







































































Original	Substituto	Original	Substituto
 Power	 Power	 Scan >>	 >>
 Open/Close	 Eject	 I<< Skip	 I<<
 Subtitle	 Subt	 Skip >>I	 >>I
 Info/Menu	 Menu	 Enter	 Ok
 Disc Menu	 D. Menu	 Up/Presets+	 Up
 Home	 Smart	 Down/Presets-	 Down
 Back	 Back	 Left/Tuning-	 Left
 Sleep	 Sleep	 Right/Tuning+	 Right
 Function	 AV	 Red	 Red
 Title/PopUp	 Info	 Green	 Green
 Vol+	 Vol +	 Yellow	 Yellow
 Vol-	 Vol -	 Blue/Mono/Stereo	 Blue
 Mute	 Mute	 1	 1
 Play	 Play	 2	 2
 Pause/Step	 Pause	 3	 3
 Stop	 Stop	 4	 4
 << Scan	 <<	 5	 5





Original	Substituto	Original	Substituto
	6		6
	7		7
	8		8
	9		9
	0		0
	Rec		Rec
	Audio		Dual
	MIC/ECHO		Options
	Repeat		Text
	Clear		Exit
	*		Guide
	Optical/Tv Sound		TV/R
	Sound Effect		3D
	Speaker Level		Format
	Power Tv		Shift + Power
	AV/Input Tv		Shift + AV
	PR/CH+ Tv		Ch +

Original	Substituto	Original	Substituto
	PR/CH- Tv		Ch -
	Vol+ Tv		Shift + Vol +
	Vol- Tv		Shift + Vol -
	Mute Tv		Shift + Mute

