































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	Recall		Back / Return
	Vol+		Vol+
	Audio/Audio/Lang/ MTS		Audio / Lang I/II
	Exit/Exit		Exit / Cancel / Clear
			P+
			Vol-
			P-
			Up
			Left
			OK
			Right
			LCD Menu
			Down
			DVB Menu
			Input
			P.Mode
			S.Mode
			Sleep
			Info/Display
			Zoom/P.Ratio
			Tv/Radio
			CH+ / Page+
			Vol-
			CH- / Page-
			Up
			Left
			OK
			Right
			Shift + D.Menu / Top Menu
			Down
			D.Menu / Top
			AV / Input / RDS
			Picture / Format
			Sound / Title
			Sleep / Timer
			Info / Angle
			Zoom / Size
			TV/Radio /





Original	Substituto
	FAV Fav / Marker / PC
	TTX Text / Goto
	Pause/Hold/Cancel Pause / Step / Freeze
	Cancel/USB/Card SHIFT + CLEAR / Exit / Cancel / Clear
	EPG/List SHIFT + GUIDE EPG / Shift + Guide / EPG / -/-
	Stop/Index/Stop HOLD / Stop / Hold
	Size SHIFT + SIZE / Zoom / Zoom /
	Play/Play SLOW / Play / Slow
	Reveal/Reveal OPT-TOOLS / Setup / OPT /
	Subtitle/Sub.PG EQ / Subtitle / EQ
	<</FR Red / Netflix / Search
	>>/FF Green / APP / Repeat
	I<</Prev PRESET- / I<< / Preset-
	>>I/Next PRESET+ / >>I / Preset+

Original	Substituto
	Blue Blue / Prime Video / Random

