



Original	Substituto	Original	Substituto
	Power		Power
	Select Drive		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	*/Delete/Reset		3D
	Input Select		AV
	CH/Tracking+		Ch +
	CH/Tracking-		Ch -
	Showview		Media

Original	Substituto	Original	Substituto
	Prog/Check		Sleep
	Slow Search >>		>>
	<< Slow Search		<<
	Skip/Index >>		>>
	<< Skip/Index		<<
	Stop		Stop
	Pause		Pause
	Play		Play
	i/Status		Info
	Exit		Exit
	Option		Options
	Return		Back
	Direct Navigator		List
	Guide		Guide
	Function Menu		Menu
	Up		Up
	Down		Down



