





































































































Original	Substituto	Original	Substituto
 Power	 Power	 Info	 Info
 3D	 3D	 P +	 Ch +
 1	 1	 P -	 Ch -
 2	 2	 W	 Shift + Smart
 3	 3	 Smart TV	 Smart
 4	 4	 @	 Media
 5	 5	 Menu	 Menu
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right / Zoom +	 Right
 9	 9	 Left / Zoom -	 Left
 0	 0	 OK	 Ok
 ECO	 Shift + 3D	 Back	 Back
 Source	 AV	 Exit	 Exit
 Vol +	 Vol +	 Option	 Options
 Vol -	 Vol -	 USB	 Shift + Media
 Mute	 Mute	 TV	 TV/R





Original	Substituto	Original	Substituto
 Sleep	 Sleep	 Rec	 Rec
 Guide	 Guide	 >>	 >>
 FAV	 Pre Ch		
 List	 List		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Lang	 Dual		
 Subtitle	 Subt		
 Text	 Text		
 I<	 I<<		
 Stop	 Stop		
 Play / Pause	 Play		
 Play / Pause	 Pause		
 >I	 >>I		
 <<	 <<		

