





































































































Original	Substituto	Original	Substituto
 Power	 Power	 Info	 Info
 3D	 3D	 P +	 Ch +
 1	 1	 P -	 Ch -
 2	 2	 W	 Shift + Smart
 3	 3	 Smart TV	 Smart
 4	 4	 @	 Media
 5	 5	 Menu	 Menu
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right / Zoom +	 Right
 9	 9	 Left / Zoom -	 Left
 0	 0	 OK	 Ok
 ECO	 Shift + 3D	 Back	 Back
 Source	 AV	 Exit	 Exit
 Vol +	 Vol +	 Option	 Options
 Vol -	 Vol -	 USB	 Shift + Media
 Mute	 Mute	 TV	 TV/R





Original		Substituto		Original		Substituto	
	Sleep		Sleep		Rec		Rec
	Guide		Guide		>>		>>
	FAV		Pre Ch				
	List		List				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play / Pause		Play				
	Play / Pause		Pause				
	>I		>>I				
	<<		<<				

