
















































Original	Substituto	Original	Substituto
 Standby	 Power	 2	 2
 Mute	 Mute / Dimmer	 3	 3
 Play	 Play / Slow	 4	 4
 Pause	 Pause / Step / Freeze	 5	 5
 Stop	 Stop / Hold	 6	 6
 Mem	 Rec / Rec Mode	 7	 7
 << Scan	 << / Tune-	 8	 8
 Scan >>	 >> / Tune+	 9	 9
 I<< Preset	 I<< / Preset-	 0	 0
 Preset >>I	 >>I / Preset+	 REP/--	 Green / APP / Repeat
 Open/Close	 Eject / Surround	 Speakers A/B	 Yellow / YouTube / Repeat
 Auto (Tuner)	 TV/Radio /	 Dimmer	 Shift + Mute / Dimmer
 Input	 AV / Input / RDS	 << Scan	 Shift + << /
 Info	 Info / Angle	 Scan >>	 Shift + >> /
 Vol+	 Vol+	 I<< Preset	 Shift + I<< / Preset-
 Vol-	 Vol-	 >>I Preset	 Shift + >>I / Preset+
 1	 1	 FM/AM (Tuner)	 Shift + 6





Original	Substituto
 Open/Close	 Eject / Surround
 Input	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Dimmer	 Shift + Mute / Dimmer
 REP/--	 Green / APP / Repeat
 Play	 Play / Slow
 Pause/Auto	 Pause / Step / Freeze
 Stop/FM/AM	 Stop / Hold

Original	Substituto
 Mem	 Rec / Rec Mode
 << Scan	 << / Tune-
 Scan >>	 >> / Tune+
 Mute	 Mute / Dimmer
 I<< Preset	 I<< / Preset-
 Preset >>I	 >>I / Preset+
 Vol+	 Vol+
 Vol-	 Vol-
 Standby	 Power
 Info	 Info / Angle
 Speakers A/B	 Yellow / YouTube / Repeat

