














































Original	Substituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Pre Ch
 Display	 Info
 P.Mode	 Media
 Text	 Text
 Red	 Red
Green	Green

Original	Substituto
 Yellow	 Yellow
 Blue	 Blue
 Up	 Up
 CH+	 Ch +
 Down	 Down
 CH-	 Ch -
 Right	 Right
 Vol+	 Vol +
 Left	 Left
 Vol-	 Vol -
 Menu	 Menu
 S.Mode	 Smart
 Mute	 Mute
 Zoom	 Eject
 Still	 Back
 O)/v/Audio	 Dual
Video	AV





Original	Substituto	Original	Substituto
	S-Video		TV/R
	PC		Options
	YPbPr		Format
	YCbCr		Subt
	Time		Sleep

