























































































Original	Substituto	Original	Substituto
 Power	 Power	 Tracking/V-Lock+	 Ch +
 ShowView	 Smart	 Tracking/V-Lock-	 Ch -
 Rec Check	 3D	 Vol+	 Vol +
 Ext Link	 Text	 Vol-	 Vol -
 Rec	 Rec	 I<< Index	 I<<
 1	 1	 Index >>I	 >>I
 2	 2	 <<	 <<
 3	 3	 >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause/Step	 Pause
 6	 6	 Play	 Play
 7	 7	 Prog Play	 Options
 8	 8	 Menu	 Menu
 9	 9	 Display	 Info
 0	 0	 Exit	 Exit
 -/..	 GUIDE	 Up	 Up
 AV/INPUT SELECT	 AV	 Down	 Down

Original	Substituto	Original	Substituto
 Power	 Power	 Tracking/V-Lock+	 Ch +
 ShowView	 Smart	 Tracking/V-Lock-	 Ch -
 Rec Check	 3D	 Vol+	 Vol +
 Ext Link	 Text	 Vol-	 Vol -
 Rec	 Rec	 I<< Index	 I<<
 1	 1	 Index >>I	 >>I
 2	 2	 <<	 <<
 3	 3	 >>	 >>
 4	 4	 Stop	 Stop
 5	 5	 Pause/Step	 Pause
 6	 6	 Play	 Play
 7	 7	 Prog Play	 Options
 8	 8	 Menu	 Menu
 9	 9	 Display	 Info
 0	 0	 Exit	 Exit
 -/..	 GUIDE	 Up	 Up
 AV/INPUT SELECT	 AV	 Down	 Down











































































































Original		Substituto	
	Right		Right
	Left		Left
	Enter		Ok
	Prog/Check		Sleep
	Timer	 + 	Shift + AV
	Output		TV/R
	AV Link		Media
	Audio		Dual
	Tv Aspect/Off		Format
	Music w/Picture		List
	A/Cancel Reset		Red
	B/I-Timer		Green
	C/SP/LP/EP		Yellow
	D/VPS/PDC		Blue

Original		Substituto





	Original	Substituto		Original	Substituto
	Power		Power		Vol+
	Rec Check		3D		Vol-
	Ext Link		Media		I<< Skip
	1		1		Skip >>I
	2		2		<< Slow/Search
	3		3		Slow/Search >>
	4		4		Stop
	5		5		Pause/Step
	6		6		Play
	7		7		Top Menu/Direct Navigator
	8		8		Play List
	9		9		Display
	0		0		Return
	>10		Guide		Up
	AV/Input Select		AV		Down
	Tracking/V-Lock/C		Ch +		Right
	Tracking/V-Lock/C		Ch -		Left

	Original	Substituto		Original	Substituto
	Vol+		Vol +		TV
	Vol-		Vol -		DVD
	I<< Skip		I<<		SAT
	Skip >>I		>>I		AUX
	<< Slow/Search		<<		PLAY MODE
	Slow/Search >>		>>		REC MODE
	Stop		Stop		PLAY
	Pause/Step		Pause		PAUSE
	Play		Play		DISC NAV
	Top Menu/Direct Navigator		Menu		SOUND
	Play List		List		AD
	Display		Info		SETTINGS
	Return		Back		LIST
	Up		Up		DUAL
	Down		Down		SUBT
	Right		Right		OPT
	Left		Left		PROG
































Original		Substituto	
	Enter		Ok
	Timer	+	Shift + AV
	Quick Replay		D. Menu
	Output		TV/R
	Subtitle		Subt
	Audio		Dual
	Angle/Page		Smart
	Music w/Picture		Pre Ch
	Play Mode	+	Shift + Play
	Zoom		Eject
	Repeat		Text
	Position		Options
	A/Cancel Reset		Red
	B/Cinema		Green
	C/Group		Yellow
	D/Setup		Blue

Original	Substituto





Original	Substituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 GUIDE
 AV	 AV
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -

Original	Substituto
 Tv Aspect	 Format
 A	 Red
 B	 Green
 C	 Yellow
 D	 Blue

