



| Original                                                                            | Substituto | Original                                                                            | Substituto                  |
|-------------------------------------------------------------------------------------|------------|-------------------------------------------------------------------------------------|-----------------------------|
|    | Power      |    | Power                       |
|    | Source     |    | AV / Input / RDS            |
|    | Rec        |    | Rec / Rec Mode              |
|    | Play       |    | Play / Slow                 |
|    | Pause      |    | Pause / Step / Freeze       |
|    | Stop       |    | Stop / Hold                 |
|    | Lang       |    | Audio / Lang I/II           |
|    | <<         |    | << / Tune-                  |
|    | >>         |    | >> / Tune+                  |
|    | [≡]..      |    | Sound / Title               |
|  | Red        |  | Red / Netflix / Search      |
|  | Green      |  | Green / APP / Repeat        |
|  | Yellow     |  | Yellow / YouTube / Repeat   |
|  | Blue       |  | Blue / Prime Video / Random |
|  | 1          |  | 1                           |
|  | 2          |  | 2                           |
|  | 3          |  | 3                           |

| Original                                                                              | Substituto | Original                                                                              | Substituto            |
|---------------------------------------------------------------------------------------|------------|---------------------------------------------------------------------------------------|-----------------------|
|    | 4          |    | 4                     |
|    | 5          |    | 5                     |
|    | 6          |    | 6                     |
|    | 7          |    | 7                     |
|    | 8          |    | 8                     |
|    | TV         |    | TV/Radio /            |
|    | 9          |    | 9                     |
|    | 0          |    | 0                     |
|    | Recall     |    | Fav / Marker / PC     |
|    | Up         |    | Up                    |
|  | Left       |  | Left                  |
|  | OK         |  | OK                    |
|  | Right      |  | Right                 |
|  | Down       |  | Down                  |
|  | Menu       |  | Menu / Home           |
|  | Back       |  | Back / Return         |
|  | Exit       |  | Exit / Cancel / Clear |



