




































































Original	Substituto	Original	Substituto
 Power	 Power	 0	 0
 Call	 Pre Ch	 -/--/---	 Guide
 Mute	 Mute	 QV	 Smart
 Source	 AV	 TV Menu	 Menu
 P.Mode	 Shift + Format	 TV / Text	 Text
 S.Mode	 Shift + Dual	 Mix	 Media
 I / II	 Dual	 Call	 Back
 Sleep	 Sleep	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 Enter	 Ok
 5	 5	 V +	 Vol +
 6	 6	 V -	 Vol -
 7	 7	 P +	 Ch +
 8	 8	 P -	 Ch -
 9	 9	 Red	 Red



