







































































Original	Substituto	Original	Substituto
	Power		Power
	Netflix		Media
	TV		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Eco		3D
	Source		AV
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	[]		Info
	P+		Ch +
	P-		Ch -
	*		Menu
	Home		Smart
	Guide		Guide
	≡		Options
	Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Exit		Exit
	Zoom+		Shift + Ch +
	Zoom-		Shift + Ch -





Original	Substituto	Original	Substituto
 List	 List	 Pause	 Pause
 Sleep	 Sleep	 >>	 >>
 PRE-CH	 Pre Ch		
 FAV	 Shift + Pre Ch		
 Rec	 Rec		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Lang	 Dual		
 Subtitle	 Subt		
 Text	 Text		
 I<	 I<<		
 Stop	 Stop		
 Play	 Play		
 >I	 >>I		
 <<	 <<		

