






| Original | Substituto |
|---|-------------------|
|  | Mute / Dimmer |
|  | Fav / Marker / PC |
|  | Power |
|  | Info / Angle |
|  | Smart / List |
|  | 1 |
|  | 2 |
|  | 3 |
|  | Stop / Hold |
|  | 4 |
|  | 5 |
|  | 6 |
|  | Subtitle / EQ |
|  | 7 |
|  | 8 |
|  | 9 |
|  | Display / Media |

| Original | Substituto |
|---|--------------------|
|  | AV / Input / RDS |
|  | 0 |
|  | Guide / EPG / -/-- |
|  | Shift + Text / |
|  | Text / Goto |
|  | CH+ / Page+ |
|  | Up |
|  | Menu / Home |
|  | Left |
|  | Vol- |
|  | OK |
|  | Right |
|  | Vol+ |
|  | Back / Return |
|  | CH- / Page- |
|  | Down |
|  | Setup / OPT / |





| Original | Substituto | Original | Substituto |
|---|---|----------|------------|
|  | Red Red / Netflix / Search | | |
|  | Green Green / APP / Repeat | | |
|  | Yellow / Timer Yellow / YouTube / Repeat | | |
|  | Blue Blue / Prime Video / Random | | |
|  | Violet Shift + Red / Netflix / | | |
|  | Picture Picture / Format | | |
|  | Sound / Title | | |
|  | Exit / Cancel / Clear | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

