



Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV / Radio		TV/R
	Recall / Mouse		Back
	P.Mode		Format
	S.Mode		Dual
	Nicam / A2	+	Shift + Dual

Original	Substituto	Original	Substituto
	Sleep		Sleep
	Source		AV
	CH +		Ch +
	CH -		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Info		Info
	Home		Smart
	FAV		Pre Ch
	Settings		Options
	ASP		List
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Menu		Menu





Original	Substituto
Exit	Exit
I<< / Text	I<<
I<< / Text	Text
>>I / Subpage	>>I
<< / Size	<<
>> / Reveal	>>
Play/Pause / Index	Play
Play/Pause / Index	Pause
Stop / Hold	Stop
Cancel	Shift + Exit
Subtitle	Subt
Repeat	Shift + Text
Auto	3D
A - B	Eject
Media	Media
Red	Red
Green	Green

Original	Substituto
Yellow	Yellow
Blue	Blue

