





































Original	Substituto
 Power	 Power
 Mute	 Mute
 P.M.	 Options
 S.M.	 Shift + Dual
 Zoom	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Return	 Back
 CHN. List / Quick	 List

Original	Substituto
 Menu	 Menu
 Source	 AV
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Exit / PVR List	 Exit
 Info	 Info
 3D	 3D
 Vol +	 Vol +
 Vol -	 Vol -
 I/II / Nicam	 Dual
 Sleep	 Sleep
 PR +	 Ch +
 PR -	 Ch -
 Subtitle	 Subt





Original	Substituto
 EPG	 Guide
 Fav	 Pre Ch
 Text	 Text
 Rec	 Rec
 Play/Pause / Index	 Play
 Play/Pause / Index	 Shift + Info
 Play/Pause / Index	 Pause
 Stop / Cancel	 Shift + Exit
 Stop / Cancel	 Stop
 Freeze / Hold	 Shift + Pause
 I<< / Size	 Shift + Eject
 I<< / Size	 I<<
 << / Reveal	 Smart
 << / Reveal	 <<
 >> / Mix	 Shift + Text
 >> / Mix	 >>
 >>I / Sub Page	 Shift + Subt

Original	Substituto
 >>I / Sub Page	 >>I
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

