



Original	Substituto	Original	Substituto
 Power	 Power	 8	 8
 Mute	 Mute	 9	 9
 Audio	 Dual	 0	 0
 TV / STB	 Shift + TV/R	 PGUP	 Vol +
 TV / R	 TV/R	 PGDN	 Vol -
 Sleep	 Sleep	 SAT	 Shift + AV
 SUB	 Subt	 FAV +	 Ch +
 TXT	 Text	 FAV -	 Ch -
 P / N	 Shift + 1	 EPG	 Guide
 Recall	 Pre Ch	 Fav	 Shift + Pre Ch
 1	 1	 Up	 Up
 2	 2	 Right	 Right
 3	 3	 Down	 Down
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 Menu	 Menu
 7	 7	 Exit	 Exit



