
































































Original		Substituto		Original		Substituto	
	Power		Power		Still		Pause
	DTV / ATV		Smart		P -		Ch -
	1		1		P +		Ch +
	2		2		V -		Vol -
	3		3		V +		Vol +
	4		4		Sleep		Sleep
	5		5		Mute		Mute
	6		6		MTS		Shift + Media
	7		7		Menu		Menu
	8		8		Source		AV
	9		9		Up		Up
	0		0		Right		Right
	-/--		Shift + Guide		Down		Down
	Recall		Back		Left		Left
	P.Mode		Shift + Format		Enter		Ok
	S.Mode		Dual		Exit		Exit
	Aspect		Format		i		Info





Original	Substituto	Original	Substituto
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text / <<		Text
	Text / <<		<<
	Hold / >>		>>
	Hold / >>		Shift + Pause
	Mix / I<<		I<<
	Mix / I<<		Shift + Text
	Timer / >>I		>>I
	[≡] / Play/Pause		Play
	[≡] / Play/Pause		Shift + Info
	Size / Stop		Stop
	Size / Stop		Eject
	[?]		D. Menu
	Subtitle		Subt

