
























































































Original	Substituto	Original	Substituto
 Power	 Power	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Guide	 Guide
 3	 3	 Menu	 Menu
 4	 4	 i	 Info
 5	 5	 Back	 Back
 6	 6	 Exit	 Exit
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Lang	 Dual	 OK	 Ok
 TXT	 Text	 Netflix	 Media
 Vol+	 Vol +	 F Play	 TV/R
 Vol-	 Vol -	 You Tube	 Smart
 Mute	 Mute	 Prime Video	 Options
 Source	 AV	 Red	 Red





Original	Substituto
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 <<	 <<
 Pause	 Pause
 >>	 >>
 Rec	 Rec
 Play	 Play
 Stop	 Stop

Original	Substituto

