

























Original	Substituto	Original	Substituto
 Power	 Power	 0	 0
 TV Set Power	 Shift + Power	 Recall	 Back
 TV Set V +	 Vol +	 Audio	 Dual
 TV Set V -	 Vol -	 Menu	 Menu
 Mute	 Mute	 Exit	 Exit
 TV Mode	 Options	 Up	 Up
 TV / Rad	 TV/R	 Right	 Right
 Find	 Media	 Down	 Down
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Sat	 AV
 4	 4	 Fav	 Pre Ch
 5	 5	 PG +	 Ch +
 6	 6	 PG -	 Ch -
 7	 7	 YouTube	 Smart
 8	 8	 Play / PauInfo	 Info
 9	 9	 EPG	 Guide





Original		Substituto		Original		Substituto	
	Play / Pause		Play				
	Play / Pause		Pause				
	<< FB		<<				
	>> FF		>>				
	Stop		Stop				
	I<< Prev		I<<				
	>>I Next		>>I				
	Sleep		Sleep				
	Sub-T		Subt				
	Text		Text				
	Rec		Rec				
	Red / IPTV		Red				
	Green / Video		Green				
	Yellow / PVR		Yellow				
	Blue / Timer		Blue				

