







































































Original	Substituto	Original	Substituto
	Power		Power
	Source		AV
	P.Mode		Format
	S.Mode		Dual
	Home		Shift + Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Q.View		D. Menu
	Info		Info

Original	Substituto	Original	Substituto
	Menu		Menu
	Guide		Guide
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Back		Back
	Exit		Exit
	Vol +		Vol +
	Vol -		Vol -
	APP Store		Media
	Mute		Mute
	Tool		Options
	CH +		Ch +
	CH -		Ch -
	FAV		Pre Ch





Original	Substituto	Original	Substituto
 APP	 Smart		
 CH. List	 List		
 <<<	 <<<		
 Play	 Play		
 >>>	 >>>		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

