



Original	Substituto	Original	Substituto
	Power		Power
	Tv/Rad		TV/R
	Subtitle		Subt
	AD/PIP/*		Dual
	Tv/PC		Media
	Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List

Original	Substituto	Original	Substituto
	Q.View		D. Menu
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	FAV		Pre Ch
	Guide		Guide
	P+		Ch +
	P-		Ch -
	Text		Text
	Info		Info
	T.Opt		Shift + Options
	Q.Menu		Menu
	Back		Back
	Settings		Options
	Exit		Exit
	Up		Up
	Down		Down





Original	Substituto	Original	Substituto
Right	Right		
Left	Left		
OK	Ok		
Simplink	Smart		
Stop	Stop		
<<	<<		
Play	Play		
Pause	Pause		
>>	>>		
Red	Red		
Green/Games	Green		
Yellow/Brightness	Yellow		
Blue/Brightness+	Blue		

