







































































Original	Substituto	Original	Substituto
 Power	 Power	 8	 8
 Mute	 Mute	 9	 9
 Timer	 Shift + AV	 0	 0
 Size	 Format	 -/--	 Guide
 Timer / Cancel [≡X]	 Exit	 Index	 Shift + Info
 Picture	 Shift + Format	 Red	 Red
 Text / Mix	 Text	 Green	 Green
 Input / Hold	 AV	 Yellow	 Yellow
 Info / Reveal	 Info	 Blue	 Blue
 Subtitle	 Subt	 Vol +	 Vol +
 1	 1	 Vol -	 Vol -
 2	 2	 Progr + / Page +	 Ch +
 3	 3	 Progr - / Page -	 Ch -
 4	 4	 <<	 <<
 5	 5	 Play	 Play
 6	 6	 >>	 >>
 7	 7	 Stop	 Stop





Original	Substituto	Original	Substituto
	Pause		Pause
	Power (lower)	+	Shift + Power
	Rec		Rec
	↑ + →>		Right
	Progr - (lower)	+	Shift + Ch -
	Progr + (lower)	+	Shift + Ch +
	[    - ](*)		Dual
	→•← C		Back
	[    - ] [← →] +		Up
	[    - ] [← →] -		Down

Original	Substituto

