







































































Original	Substituto	Original	Substituto
 Power	 Power	 Info	 Info
 Mute	 Mute	 EPG	 Guide
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 OK	 Ok
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 Menu	 Menu
 7	 7	 Exit	 Exit
 8	 8	 Vol +	 Vol +
 9	 9	 Vol -	 Vol -
 0	 0	 P +	 Shift + Ch +
 TV / R	 TV/R	 List	 List
 Home	 Smart	 P -	 Shift + Ch -
 FAV	 Pre Ch	 CH +	 Ch +
 Back	 Back	 CH -	 Ch -
 Audio	 Dual	 OPT	 Options

Original	Substituto	Original	Substituto
 MUTE	 MUTE	 SHIFT	
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 TV	 DUAL
 TV	 SUBT	 OPT	 ECO
 SLEEP	 TV/R	 FORMAT	 3D
 E-MANUAL	 REPEAT	 ZOOM	 TIMER
 D.MENU	 TEXT	 AV	
 TOP MENU MENU	 INFO	 OK	
 CLEAR	 EXIT	 RETURN BACK	
 VOL +	 HOME SMART	 VOL +	
 VOL -	 APP MEDIA	 VOL -	
 P +	 CH +	 1	 2
 LIST	 DISC NAV LIST	 3	 4
 P -	 CH -	 5	 6
 CH +	 CH +	 7	 8
 CH -	 CH -	 9	 0
OPT	SETTINGS OPT	 GUIDE	 PRE-CH
		A	B
		C	D
		www.mandis.tv	





	Original	Substituto		Original	Substituto
	Text				
	SUB				
	Message				
	Pause				
	<<				
	>>				
	Rec				
	Play				
	I<<				
	>>I				
	Stop				
	Red				
	Green				
	Yellow				
	Blue				

