







































































Original	Substituto	Original	Substituto
 Power	 Power	 Vol-	 Vol-
 TV	 TV/Radio /	 Source	 AV / Input / RDS
 1	 1	 P -	 CH- / Page-
 2	 2	 Info	 Info / Angle
 3	 3	 Menu	 Menu / Home
 4	 4	 Guide	 Guide / EPG / -/-
 5	 5	 Tools	 Setup / OPT /
 6	 6	 Up	 Up
 7	 7	 Return	 Shift + Back / Return
 8	 8	 Left	 Left
 9	 9	 Enter	 OK
 FAV CH	 Fav / Marker / PC	 Right	 Right
 0	 0	 Internet	 Smart / List
 PRE CH	 Back / Return	 Down	 Down
 Vol+	 Vol+	 Exit	 Exit / Cancel / Clear
 Mute	 Mute / Dimmer	 Red	 Red / Netflix / Search
 P +	 CH+ / Page+	 Green	 Green / APP / Repeat





Original	Substituto	Original	Substituto
	Yellow	 <small>REPEAT A-B</small>	Yellow / YouTube / Repeat
	Blue	 <small>RANDOM</small>	Blue / Prime Video / Random
	TTX/MIX	 <small>GOTO</small>	Text / Goto
	Media P	 <small>MEDIA</small>	Display / Media
	Content	 <small>TOP MENU</small>	D.Menu / Top
	CH LIST	 <small>SHIFT</small> + <small>LIST SMART</small>	Shift + Smart / List
	AD	 <small>LANG I/II</small>	Audio / Lang I/II
	SUBT	 <small>EQ</small>	Subtitle / EQ
	<<	 <small>TUNE-</small>	<< / Tune-
	Pause	 <small>STEP-FREEZE</small>	Pause / Step / Freeze
	>>	 <small>TUNE+</small>	>> / Tune+
	Rec	 <small>REC MODE</small>	Rec / Rec Mode
	Play	 <small>SLOW</small>	Play / Slow
	Stop	 <small>HOLD</small>	Stop / Hold

