



































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	--/10+	 + 	Shift + Guide
	Recall		Back
	Subtitle		Subt
	P.Mode	 + 	Shift + Format
	S.Mode		Dual

Original	Substituto	Original	Substituto
	MTS		Media
	Sleep		Sleep
	Source		AV
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Info		Info
	Freeze		Red
	CH.List		List
	Auto		Yellow
	Aspect		Format
	Up		Up
	Down		Down
	OK		Ok
	Right		Right
	Left		Left





Original		Substituto		Original		Substituto	
	Menu		Menu		<<		<<
	Exit		Exit		>>		>>
	CC		Smart				
	Eject / V-Chip		Eject				
	Play/Pause / FAV		Play				
	Play/Pause / FAV		Pre Ch				
	Stop/ADD/Erase		Stop				
	Title		Options				
	Setup/EPG		Guide				
	Audio		Shift + Dual				
	Goto		TV/R				
	A-B		Shift + Text				
	Menu (lower)		D. Menu				
	Slow		Pause				
	Repeat		Text				
	<<		<<				
	>>		>>				

