



Original	Substituto	Original	Substituto
 Standby	 Power	 Down	 Down
 Mute	 Mute	 Right	 Right
 P/N	 Smart	 Left	 Left
 Open/Close	 Eject	 OK	 Ok
 <<	 <<	 Vol+	 Vol +
 >>	 >>	 Vol-	 Vol -
 Play/Pause	 Play	 1	 1
 Stop	 Stop	 2	 2
 I<<	 I<<	 3	 3
 >>I	 >>I	 4	 4
 Setup	 Options	 5	 5
 Source	 AV	 6	 6
 Info	 Info	 7	 7
 Return/Exit	 Exit	 8	 8
 CH+	 Ch +	 9	 9
 CH-	 Ch -	 0	 0
 Up	 Up	 Slow	 Back

Original	Substituto	Original	Substituto
 Down	 Down	 Right	 Right
 Left	 Left	 OK	 Ok
 Vol+	 Vol +	 Vol-	 Vol -
 1	 1	 2	 2
 3	 3	 4	 4
 5	 5	 6	 6
 7	 7	 8	 8
 9	 9	 0	 0
 Slow	 Back		





Original	Substituto	Original	Substituto
 Goto	 Media		
 Program	 Sleep		
 Title/TTX	 Text		
 Audio	 Dual		
 Subtitle	 Subt		
 Red/Repeat	 Red		
 Green/A-B	 Green		
 Yellow/Menu	 Yellow		
 Blue/Angle	 Blue		
 EPG	 Guide		
 Favorite	 Pre Ch		
 Tv/Radio	 TV/R		
 Zoom	 Shift + Eject		

