



Original	Substituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back
 Still	 Pause
 TV / Input	 AV
 Multimedia	 Media
 Zoom -	 Shift + Down
 Zoom +	 Shift + Up

Original	Substituto
 Up / PR +	 Up
 Up / PR +	 Ch +
 Down / PR -	 Down
 Down / PR -	 Ch -
 Right / Vol +	 Right
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 Menu	 Menu
 Menu	 Ok
 Prev PR	 Pre Ch
 Screen Size	 3D
 Mute	 Mute
 Sleep	 Sleep
 [≡]	 Text
 [≡?]	 Smart
 [≡X]	 Exit

























































Original	Substituto	Original	Substituto
[≡⇅]	Eject		
[≡●]	TV/R		
[≡□]	Stop		
Pic Mode / [ /≡]	Format		
Sound Mode / [≡i]	Dual		
	Red		
	Green		
	Yellow		
Blue / I-II	Blue		
Blue / I-II	Shift + Dual		





Original	Substituto	Original	Substituto
 Power	 Power	 Menu	 Ok
 1	 1	 << FR / Slow	 <<
 2	 2	 Play	 Play
 3	 3	 >> FF / Slow	 >>
 4	 4	 Stop	 Stop
 5	 5	 I<< Prev	 I<<
 6	 6	 Open / Close	 Eject
 7	 7	 >>I Next	 >>I
 8	 8	 Pause	 Pause
 9	 9		
 0	 0		
 TV / Input	 AV		
 Up / PR +	 Up		
 Up / PR +	 Ch +		
 Down / PR -	 Down		
 Down / PR -	 Ch -		
 Menu	 Menu		





Original	Substituto	Original	Substituto
Power	Power	Red	Red
1	1	Green	Green
2	2	Yellow	Yellow
3	3	Blue / I-II	Blue
4	4	Blue / I-II	Dual
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Up / PR +	Up		
Up / PR +	Ch +		
Down / PR -	Down		
Menu	Ok		
Down / PR -	Ch -		
Menu	Menu		

Original	Substituto	Original	Substituto
Red	Red		
Green	Green		
Yellow	Yellow		
Blue / I-II	Blue		
Blue / I-II	Dual		

