










	Original	Substituto		Original	Substituto
	Power		Power		Right
	Mute		Mute		Down
	1		1		Left
	2		2		OK
	3		3		Ch. List
	4		4		Exit
	5		5		Vol +
	6		6		Vol -
	7		7		Sound
	8		8		Ch +
	9		9		Ch -
	0		0		PIC
	Audio		Dual		Shift + Format
	Recall		Back		Text
	TV Menu		Menu		Aspect
	Source		AV		Freeze
	Up		Up		EPG
					Sleep



