







































































Original	Substituto	Original	Substituto
 Standby / On	 Power	 Vol +	 Vol +
 Function	 AV	 Vol -	 Vol -
 Open / Close	 Eject	 Mute	 Mute
 Karaoke	 TV/R	 Top Menu	 Shift + Menu
 Key / Echo	 Guide	 Menu / PopUp	 Menu
 NET Contents	 Media	 Home Menu	 Smart
 YouTube	 Shift + Media	 Up	 Up
 Sleep	 Sleep	 Left	 Left
 Exit	 Exit	 Return	 Back
 Mic Vol +	 Ch +	 Enter	 Ok
 Mic Vol -	 Ch -	 Right	 Right
 Home Media	 Shift + Smart	 Down	 Down
 Dimmer	 Shift + Mute	 Resolution	 Format
 CD / SACD	 D. Menu	 Replay	 Shift + Play
 Display	 Info	 Continued	 List
 USB REC	 Rec	 Tools	 Options
 Sound	 Shift + Dual	 Skip Search	 Shift + Right





Original	Substituto	Original	Substituto
<< REV	<<	Clear	Shift + Exit
Play	Play	Repeat	Text
>> FWD	>>	Subtitle	Subt
I<< / < / <	I<<	Angle	Shift + Format
Pause	Pause	Virtual 3D Sound	3D
Stop	Stop	A-B	Shift + Text
>> / > / >	>>	Program / Red	Red
1	1	Program / Red	Shift + Sleep
2	2	RDS / Bookmark / Green	Green
3	3	Audio	Dual
4	4	RDS / Bookmark / Green	Pre Ch
5	5	PTY / Zoom /	Yellow
6	6	PTY / Zoom /	Shift + Eject
7	7	Index / Blue	Blue
8	8		
9	9		
0	0		

