
































































































Original	Substituto	Original	Substituto
 Power	 Power	 Stop	 Stop
 Source	 AV	 <<	 <<
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Mute	 Mute
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Menu	 Menu
 0	 0	 Exit	 Exit
 -/--	 Guide	 Up	 Up
 PRE-CH	 Pre Ch	 Down	 Down
 TV	 TV/R	 Right	 Right
 CH.MGR	 Smart	 Left	 Left
 Wiselink	 Media	 Enter	 Ok























































Original	Substituto	Original	Substituto
 [= ?]/Info	 Info	1	1 Cable
 [= +]/PIP	 3D	2	2 Cable
 TTX/MIX	 Text	3	3 Cable
 Red	 Red	4	4 Cable
 Green	 Green	5	5 Cable
 Yellow	 Yellow	6	6 Cable
 Blue	 Blue	7	7 Cable
 I-II/Dual	 Dual	8	8 Cable
 (O)/SRS	 Back	9	9 Cable
 Source (Green)	 Shift + AV	0	0 Cable
 PC	 List		P+ Cable
 [▼]/STTL	 Subt		P- Cable
 [<>]/Size	 Format		
 [= ♦]/P.Mode	 Shift + Format		
 [=]/S.Mode	 Options		
 Sleep	 Sleep		
 Power Cable	 Shift + Power		



































































Original	Substituto	Original	Substituto
 Power	 Power	 Menu	 Menu
 1	 1	 Exit	 Exit
 2	 2	 Enter	 Ok
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 [≡?]/Info	 Info
 8	 8		
 9	 9		
 0	 0		
 TV	 TV/R		
 <<	 <<		
 Stop	 Stop		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		





Original	Substituto	Original	Substituto
 Power	 Power	 Stop	 Stop
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Menu	 Menu
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter	 Ok
 PRE-CH	 Pre Ch	 [≡?]/Info	 Info
 TV	 TV/R	 [<>]/Size	 Format
 Sleep	 Sleep	 Source	 AV
 P+	 Ch +		
 P-	 Ch -		
 <<	 <<		

Original	Substituto	Original	Substituto
 Power	 Power	 Stop	 Stop
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Menu	 Menu
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter	 Ok
 PRE-CH	 Pre Ch	 [≡?]/Info	 Info
 TV	 TV/R	 [<>]/Size	 Format
 Sleep	 Sleep	 Source	 AV
 P+	 Ch +		
 P-	 Ch -		
 <<	 <<		





Original	Substituto	Original	Substituto
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Up	Up
3	3	Enter	Ok
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Menu	Menu
8	8	Exit	Exit
9	9	[≡?]/Info	Info
0	0		
TV	TV/R		
<<	<<		
Stop	Stop		
Play	Play		
Pause	Pause		
>>	>>		

Original	Substituto	Original	Substituto
P+	Ch +	P-	Ch -
Up	Up	Down	Down
Enter	Ok	Right	Right
Down	Down	Left	Left
Menu	Menu	Exit	Exit
[≡?]/Info	Info		

