

















































Original	Substituto	Original	Substituto
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Display	 Shift + Info
Update	 List	Menu Off	 Exit
Reveal	 Dual	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Chan.Down	 Ch -
Menu video	 Options	1	 1
Text	 Text	2	 2
Txt Expand	 Eject	3	 3
TV/AV	 AV	4	 4
Menu	 Menu	5	 5
Menu Up	 Up	6	 6
Menu Left	 Left	7	 7
OK Enter	 Ok	8	 8



Original	Substituto
9	 9
Guide -/-- 1.	 Guide
0/10	 0
Disp	 +  Shift + AV
Aft/Caf	 +  Shift + 3D
2.Fav P/C 2.	 Pre Ch
Red	 Red
Green	 Green
Yellow	 Yellow
Rotate Text	 D. Menu
Mix Scan	 Smart
Store Text	 +  Shift + Text
Bright+ Mode	 3D
Browse	 Media
Blue	 Blue
Tone-	 +  Shift + Vol -
Contrast+	 +  Shift + Ch +

Original	Substituto
Tune-	 <<
Tune+	 >>
Contrast-	 +  Shift + Ch -
Surround	 +  Shift + Red
4.# 16:9	 Format
Nicam/Mono	 +  Shift + Green
Color+ P.Std	 +  Shift + Format
Level L	 +  Shift + Yellow
Level R/Woofer	 +  Shift + Blue
Audio+	 >>
Tone+	 +  Shift + Vol +
Audio-	 <<

