







































































































Original	Substituto	Original	Substituto
	Standby		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Guide		Guide
	Tools		Options
	Info		Info
	Return / Back		Back
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Smart Hub		Smart
	Red		Red
	Green		Green
	Yellow		Yellow





Original	Substituto	Original	Substituto
 Blue	 Blue		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Rec	 Rec		
 >>	 >>		
 >>	 >>		
 <<	 <<		
 <<	 <<		
 AD/Subt.	 Subt		
 3D	 3D		
 History	 Format		
 Support	 Dual		
 Camera	 Shift + Smart		
 D	 TV/R		
 CH List	 List		

