
















































































Original		Substituto		Original		Substituto	
	System Power		Power		Volume+		Vol+
	Mute		Mute / Dimmer		Preset/CH+		CH+ / Page+
	Music		Sound / Title		Volume-		Vol-
	Stereo		Audio / Lang I/II		Preset/CH-		CH- / Page-
	Night		Subtitle / EQ		1		1
	Entertain		Eject / Surround		2		2
	Straight / Effect		Picture / Format		3		3
	Level		Zoom / Size		4		4
	Sleep		Sleep / Timer		5		5
	Movie		TV/Radio /		6		6
	Set Menu		Menu / Home		7		7
	Up		Up		8		8
	A/B/C/D/E		Info / Angle		Multi CH In		9
	Left		Left		Standby		Shift + Power
	Select		OK		DTV/CBL		Shift + 1
	Right		Right		DVD		Shift + 2
	Down		Down		CD		Shift + 3





	Original	Substituto	Original	Substituto
	VCR	 +  Shift + 4		
	TUNER	 +  Shift + 6		
	V-AUX	 +  Shift + 7		
	MD / CD-R	 +  Shift + 9		

