






































































| Original | | Substituto | | Original | | Substituto | |
|---|------------|---|--------|---|-------------|---|---------|
|  | Power DVD |  | Power |  | A-B/Repeat |  | Options |
|  | Display |  | Info |  | Clear |  | Exit |
|  | SYS Video |  | Back |  | FTS/Program |  | Sleep |
|  | On/Off PBC |  | Media |  | Menu System |  | Menu |
|  | 1 |  | 1 |  | Menu Disc |  | D. Menu |
|  | 2 |  | 2 |  | Up |  | Up |
|  | 3 |  | 3 |  | Down |  | Down |
|  | 4 |  | 4 |  | Right |  | Right |
|  | 5 |  | 5 |  | Left |  | Left |
|  | 6 |  | 6 |  | OK |  | Ok |
|  | 7 |  | 7 |  | Stop/Return |  | Stop |
|  | 8 |  | 8 |  | Play |  | Play |
|  | 9 |  | 9 |  | Pause |  | Pause |
|  | 0 |  | 0 |  | >> |  | >> |
|  | +10 |  | Guide |  | << |  | << |
|  | Title |  | Pre Ch |  | > |  | >> |
|  | Repeat |  | Text |  | < |  | << |



