



Original		Substituto		Original	Substituto
	POWER		Power		
	Freeze		Mode		
	MENU / EXIT		Menu		
	AUTO		Auto		
	UP / KEYSTONE		Up		
	DOWN / KEYST.		Down		
	LEFT		Left		
	ENTER / MODE		Enter		
	RIGHT / LOCK		Right		
	Blank		Blank / Mute		
	SOURCE		Source		
	VOLUME+		Vol + / Page +		
	VOLUME-		Vol - / Page -		
	Magnify +		+ / Play		
	Magnify -		- / Stop		
	TIMER ON		Freeze / Timer		
	TIMER SET UP		Shift + Freeze / Timer		

