







































































Original	Substituto	Original	Substituto
	Power		Power
	TV / STB		TV/R
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Back / AV		Back
	V+		Vol +
	V-		Vol -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Exit		Exit
	TV Out		Media
	Guia TV		Guide
	Video Clube		Smart
	Stop		Stop
	Play		Play
	Pause		Pause
	Rec		Rec
	I<		I<<
	<<		<<





Original		Substituto		Original		Substituto	
	>>		>>				
	>		>>				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	Record List		List				

