






































































| Original | Substituto | Original | Substituto |
|--|--|---|--|
|  Power |  Power |  Info |  Info |
|  Tv/Radio |  TV/R |  Exit |  Exit |
|  Mute |  Mute |  Up |  Up |
|  1 |  1 |  Down |  Down |
|  2 |  2 |  Right |  Right |
|  3 |  3 |  Left |  Left |
|  4 |  4 |  OK |  Ok |
|  5 |  5 |  CH+ |  Ch + |
|  6 |  6 |  CH- |  Ch - |
|  7 |  7 |  Vol+ |  Vol + |
|  8 |  8 |  Vol- |  Vol - |
|  9 |  9 |  Red/F1 |  Red |
|  0 |  0 |  Green/F2 |  Green |
|  EPG |  Guide |  Yellow/F3 |  Yellow |
|  Recall |  Back |  Blue/F4 |  Blue |
|  Menu |  Menu |  Subt |  Subt |
|  FAV |  Pre Ch |  Audio |  Dual |





| Original | Substituto | Original | Substituto |
|-------------|---|---------------|---|
| On/Off |  Power | Chan.Up |  Ch + |
| Mute |  Mute | Volume- |  Vol - |
| Update |  Smart | Menu audio |  Dual |
| Subt.List |  Subt | Chan.Down |  Ch - |
| Info |  Info | 1 |  1 |
| Sleep Timer |  Sleep | 2 |  2 |
| Return TV |  TV/R | 3 |  3 |
| Text |  Text | 4 |  4 |
| Menu |  Menu | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Menu Left |  Left | 7 |  7 |
| OK Enter |  Ok | 8 |  8 |
| Menu Right |  Right | 9 |  9 |
| Menu Off |  Exit | Guide -/-- 1. |  Guide |
| Menu Down |  Down | 0/10 |  0 |
| Back |  Back | Red |  Red |
| Volume+ |  Vol + | Green |  Green |



