






























































| Original | Substituto |
|---|--|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  PP |  Back |
|  List / Menu |  Menu |
|  ? / Picture |  Format |
|  Mute |  Mute |
|  i / Display |  Info |
|  Up / P+ |  Up |

| Original | Substituto |
|--|--|
|  Down / P- |  Down |
|  Right / V+ |  Right |
|  Left / V- |  Left |
|  OK |  Ok |
|  Up / P+ |  Ch + |
|  Down / P- |  Ch - |
|  Right / V+ |  Vol + |
|  Left / V- |  Vol - |
|  EPG |  Guide |
|  TVTV |  TV/R |
|  Exit |  Exit |
|  Red / << |  Red |
|  Green / Stop |  Green |
|  Yellow / I> |  Yellow |
|  Blue / >> / VT |  Blue |
|  Rec |  Rec |
|  Jump / Source |  Smart |



