

























| Original | Substituto                 |
|----------|----------------------------|
|          | Mute                       |
|          | MUTE / Dimmer              |
|          | Power                      |
|          | TV                         |
|          | PROGRAM TV/RADIO           |
|          | TV/Radio /                 |
|          | SHIFT +  2                 |
|          | Shift + 2                  |
|          | SHIFT +                    |
|          | Shift + TV/Radio / Program |
|          | SHIFT +                    |
|          | Shift + Rec / Rec Mode     |
|          | SHIFT +                    |
|          | Shift + Yellow / YouTube / |
|          | LANG I/II                  |
|          | Audio / Lang I/II          |
|          |                            |
|          | 1                          |
|          |                            |
|          | 2                          |
|          |                            |
|          | 3                          |
|          |                            |
|          | 4                          |
|          |                            |
|          | 5                          |
|          |                            |
|          | 6                          |
|          |                            |
|          | 7                          |
|          |                            |
|          | 8                          |
|          |                            |
|          | 9                          |

| Original | Substituto            |
|----------|-----------------------|
|          | 0/AV                  |
|          | 0                     |
|          | EPG/DVD-AV            |
|          | Guide / EPG / -/-     |
|          | ASSIST/Card           |
|          | Smart / List          |
|          | PICTURE               |
|          | Picture / Format      |
|          | GOTO TEXT             |
|          | Text / Goto           |
|          | HOME MENU             |
|          | Menu / Home           |
|          | CLEAR EXIT            |
|          | Exit / Cancel / Clear |
|          | ANGLE INFO            |
|          | Info / Angle          |
|          |                       |
|          | Vol+                  |
|          |                       |
|          | Up                    |
|          |                       |
|          | CH+ / Page+           |
|          |                       |
|          | Left                  |
|          |                       |
|          | OK                    |
|          |                       |
|          | Right                 |
|          |                       |
|          | Vol-                  |
|          |                       |
|          | Down                  |
|          |                       |
|          | CH- / Page-           |





| Original  | Substituto  | Original | Substituto |
|---|---|----------|------------|
|  Red/C-Set   |  Red / Netflix / Search      |          |            |
|  Green/SV    |  Green / APP / Repeat        |          |            |
|  Yellow/Zoom |  Yellow / YouTube / Repeat   |          |            |
|  Blue/Marker |  Blue / Prime Video / Random |          |            |
|              |  << / Tune-                  |          |            |
|              |  Play / Slow                 |          |            |
|              |  >> / Tune+                  |          |            |
|              |  Rec / Rec Mode              |          |            |
|              |  Shift + Stop /              |          |            |
|             |  Pause / Step / Freeze      |          |            |
|            |  Stop / Hold               |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |
|   |   |          |            |




























| Original | Substituto                            |
|----------|---------------------------------------|
|          | Mute                                  |
|          | Mute / Dimmer                         |
|          | Power                                 |
|          | TV                                    |
|          | PROGRAM TV/RADIO                      |
|          | Shift + 2                             |
|          | Shift + TV/RADIO / Program            |
|          | Shift + Rec / Rec Mode                |
|          | Shift + Yellow / YouTube / REPEAT A-B |
|          | LANG I/II                             |
|          | Audio / Lang I/II                     |
|          | 1                                     |
|          | 1                                     |
|          | 2                                     |
|          | 2                                     |
|          | 3                                     |
|          | 3                                     |
|          | 4                                     |
|          | 4                                     |
|          | 5                                     |
|          | 5                                     |
|          | 6                                     |
|          | 6                                     |
|          | 7                                     |
|          | 7                                     |
|          | 8                                     |
|          | 8                                     |
|          | 9                                     |
|          | 9                                     |

| Original | Substituto            |
|----------|-----------------------|
|          | 0/AV                  |
|          | 0                     |
|          | EPG/DVD-AV            |
|          | Guide / EPG / -/-     |
|          | Assist/Card           |
|          | Smart / List          |
|          | Picture / Format      |
|          | Text / Goto           |
|          | Menu / Home           |
|          | Exit / Cancel / Clear |
|          | Info / Angle          |
|          | Vol+                  |
|          | Up                    |
|          | CH+ / Page+           |
|          | Left                  |
|          | OK                    |
|          | Right                 |
|          | Vol-                  |
|          | Down                  |
|          | CH- / Page-           |







































| Original  | Substituto   | Original | Substituto |
|---|--|----------|------------|
|  Red/C-Set   |  Red / Netflix / Search   |          |            |
|  Green/SV    |  Green / APP / Repeat   |          |            |
|  Yellow/Zoom |  Yellow / YouTube / Repeat  |          |            |
|  Blue/Marker |  Blue / Prime Video / Random  |          |            |
|              |  << / Tune-   |          |            |
|              |  Play / Slow  |          |            |
|              |  >> / Tune+   |          |            |
|  Rec         |  +  Shift + Stop / |          |            |
|  Rec         |  Rec / Rec Mode   |          |            |
|  Pause      |  Pause / Step / Freeze   |          |            |
|  Stop      |  Stop / Hold  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |
|   |  |          |            |





| Original  | Substituto  |
|---|---|
|    |  Power                 |
|    |  Mute / Dimmer         |
|    |  Play / Slow           |
|    |  Pause / Step / Freeze |
|    |  Stop / Hold           |
|    |  Rec / Rec Mode        |
|    |  << / Tune-            |
|    |  >> / Tune+            |
|    |  Audio / Lang I/II     |
|    |  Picture / Format      |
|   |  TV/Radio /           |
|  |  Text / Goto         |
|  |  Menu / Home         |
|  |  Up                  |
|  |  Info / Angle        |
|  |  Left                |
|  |  OK                  |

| Original  | Substituto  |
|---|---|
|    |  Right                 |
|    |  Exit / Cancel / Clear |
|    |  Down                  |
|    |  Vol+                  |
|    |  Smart / List          |
|    |  CH+ / Page+           |
|    |  Vol-                  |
|    |  CH- / Page-           |
|    |  1                     |
|    |  2                     |
|   |  3                    |
|  |  4                   |
|  |  5                   |
|  |  6                   |
|  |  7                   |
|  |  8                   |
|  |  9                   |






























































| Original    | Substituto                  | Original | Substituto |
|-------------|-----------------------------|----------|------------|
| EPG/DVD-AV  | Guide / EPG / -/--          |          |            |
| 0/AV        | 0                           |          |            |
| Red/C-Set   | Red / Netflix / Search      |          |            |
| Green/SV    | Green / APP / Repeat        |          |            |
| Yellow/Zoom | Yellow / YouTube / Repeat   |          |            |
| Blue/Marker | Blue / Prime Video / Random |          |            |
| Rec         | Shift + Stop /              |          |            |
| Rec Menu    | Shift + Rec / Rec Mode      |          |            |
| Radio       | Shift + TV/Radio / Program  |          |            |
| DVD         | Shift + 2                   |          |            |
| [-] / ← AB  | Shift + Yellow / YouTube /  |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |
|             |                             |          |            |





| Original    | Substituto  | Original    | Substituto  |
|-------------|---|-------------|---|
| Power       |  Power                 | Right       |  Right                 |
| Mute        |  Mute / Dimmer         | End         |  Exit / Cancel / Clear |
| Play        |  Play / Slow           | Down        |  Down                  |
| Pause       |  Pause / Step / Freeze | Vol+        |  Vol+                  |
| Stop        |  Stop / Hold           | Assist/Card |  Smart / List          |
| Rec         |  Rec / Rec Mode        | P+          |  CH+ / Page+           |
| <<          |  << / Tune-            | Vol-        |  Vol-                  |
| >>          |  >> / Tune+            | P-          |  CH- / Page-           |
| Audio       |  Audio / Lang I/II     | 1           |  1                     |
| PIP         |  Picture / Format     | 2           |  2                    |
| TV          |  TV/Radio /          | 3           |  3                   |
| Text/Disc-M |  Text / Goto         | 4           |  4                   |
| Menu        |  Menu / Home         | 5           |  5                   |
| Up          |  Up                  | 6           |  6                   |
| Info        |  Info / Angle        | 7           |  7                   |
| Left        |  Left                | 8           |  8                   |
| OK          |  OK                  | 9           |  9                   |

| Original    | Substituto  | Original    | Substituto  |
|-------------|---|-------------|---|
| Power       |  Power                 | Right       |  Right                 |
| Mute        |  Mute / Dimmer         | End         |  Exit / Cancel / Clear |
| Play        |  Play / Slow           | Down        |  Down                  |
| Pause       |  Pause / Step / Freeze | Vol+        |  Vol+                  |
| Stop        |  Stop / Hold           | Assist/Card |  Smart / List          |
| Rec         |  Rec / Rec Mode        | P+          |  CH+ / Page+           |
| <<          |  << / Tune-            | Vol-        |  Vol-                  |
| >>          |  >> / Tune+            | P-          |  CH- / Page-           |
| Audio       |  Audio / Lang I/II     | 1           |  1                     |
| PIP         |  Picture / Format     | 2           |  2                    |
| TV          |  TV/Radio /          | 3           |  3                   |
| Text/Disc-M |  Text / Goto         | 4           |  4                   |
| Menu        |  Menu / Home         | 5           |  5                   |
| Up          |  Up                  | 6           |  6                   |
| Info        |  Info / Angle        | 7           |  7                   |
| Left        |  Left                | 8           |  8                   |
| OK          |  OK                  | 9           |  9                   |





| Original       | Substituto                  |
|----------------|-----------------------------|
| EPG/DVD-AV     | Guide / EPG / -/--          |
| 0/AV           | 0                           |
| Red/C-Set      | Red / Netflix / Search      |
| Green/SV       | Green / APP / Repeat        |
| Yellow/Zoom    | Yellow / YouTube / Repeat   |
| Blue/Marker    | Blue / Prime Video / Random |
| Rec            | Shift + Stop /              |
| Rec Menu       | Shift + Rec / Rec Mode      |
| Radio          | Shift + TV/Radio / Program  |
| DVD            | Shift + 2                   |
| - [ ] / ← → AB | Shift + Yellow / YouTube /  |
|                |                             |
|                |                             |
|                |                             |
|                |                             |
|                |                             |
|                |                             |
|                |                             |
|                |                             |
|                |                             |
|                |                             |

| Original | Substituto |
|----------|------------|
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |
|          |            |

