








































































Original	Substituto	Original	Substituto
	Power		Power
	TV		TV/Radio /
	Radio		Shift + TV/Radio / Program
	Subtitle		Subtitle / EQ
	ALT		Smart / List
	ARC		Display / Media
	TV Guide		Guide / EPG / -/--
	Mute		Mute / Dimmer
	Language		Audio / Lang I/II
	PG		Sound / Title
	Info		Info / Angle
	Exit		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	P+		CH+ / Page+
	V+		Vol+
	P-		CH- / Page-
	V-		Vol-
	Red		Red / Netflix / Search
	White		Fav / Marker / PC
	Green		Green / APP / Repeat
	Blue		Blue / Prime Video / Random
	Yellow		Yellow / YouTube / Repeat
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8









































































Original		Substituto		Original		Substituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				





Original	Substituto	Original	Substituto
	Power		Power
	TV		TV/Radio /
	Radio		Shift + TV/Radio / Program
	Subtitle		Subtitle / EQ
	ALT		Smart / List
	ARC		Display / Media
	TV Guide		Guide / EPG / -/--
	Mute		Mute / Dimmer
	Language		Audio / Lang I/II
	PG		Sound / Title
	Info		Info / Angle
	Exit		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	P+		CH+ / Page+
	V+		Vol+
	P-		CH- / Page-
	V-		Vol-
	Red		Red / Netflix / Search
	White		Fav / Marker / PC
	Green		Green / APP / Repeat
	Blue		Blue / Prime Video / Random
	Yellow		Yellow / YouTube / Repeat
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8









































































Original		Substituto		Original		Substituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				





Original	Substituto	Original	Substituto
	Power		Power
	TV		TV/Radio /
	Radio		Shift + TV/Radio / Program
	Subtitle		Subtitle / EQ
	ALT		Smart / List
	ARC		Display / Media
	TV Guide		Guide / EPG / -/--
	Mute		Mute / Dimmer
	Language		Audio / Lang I/II
	PG		Sound / Title
	Info		Info / Angle
	Exit		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	P+		CH+ / Page+
	V+		Vol+
	P-		CH- / Page-
	V-		Vol-
	Red		Red / Netflix / Search
	White		Fav / Marker / PC
	Green		Green / APP / Repeat
	Blue		Blue / Prime Video / Random
	Yellow		Yellow / YouTube / Repeat
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8









































































Original		Substituto		Original		Substituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				





Original	Substituto	Original	Substituto
 Power	 Power	 P+	 CH+ / Page+
 TV	 TV/Radio /	 V+	 Vol+
 Radio	 Shift + TV/Radio / Program	 P-	 CH- / Page-
 Subtitle	 Subtitle / EQ	 V-	 Vol-
 ALT	 Smart / List	 Red	 Red / Netflix / Search
 ARC	 Display / Media	 White	 Fav / Marker / PC
 TV Guide	 Guide / EPG / -/--	 Green	 Green / APP / Repeat
 Mute	 Mute / Dimmer	 Blue	 Blue / Prime Video / Random
 Language	 Audio / Lang / I/II	 Yellow	 Yellow / YouTube / Repeat
 PG	 Sound / Title	 1	 1
 Info	 Info / Angle	 2	 2
 Exit	 Exit / Cancel / Clear	 3	 3
 Up	 Up	 4	 4
 Left	 Left	 5	 5
 OK	 OK	 6	 6
 Right	 Right	 7	 7
 Down	 Down	 8	 8





Original		Substituto		Original		Substituto	
	9		9				
	Menu		Menu / Home				
	Help		Text / Goto				
	0		0				

