






































































Original	Substituto	Original	Substituto
	Mute		Mute / Dimmer
	Power		Power
	Prog		TV/Radio /
	I-II		Audio / Lang I/II
	O to O		Sound / Title
	PP		Back / Return
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	--		Guide / EPG / --
	ZAP		Smart / List
	Up / P+		Up
	Up / P+		CH+ / Page+
	Right / Vol+		Right
	Right / Vol+		Vol+
	Left / Vol-		Left
	Left / Vol-		Vol-
	Normal		OK
	Down / P-		Down
	Down / P-		CH- / Page-
	Red / Memo		Red / Netflix / Search
	Green / Audio		Green / APP / Repeat
	Green / Audio		Shift + Audio / Lang I/II
	Yellow / Video		Yellow / YouTube / Repeat
	Blue / Extra		Blue / Prime Video / Random
	[ ]		Display / Media
	[ + ]		Stop / Hold





Original	Substituto
[ ◆ ]	<b>OPT-TOOLS SETUP</b> Setup / OPT /
[ ]↔	<b>TOP MENU D.MENU</b> D.Menu / Top
[≡]	<b>GOTO TEXT</b> Text / Goto
[ /≡ ]	<b>SHIFT + GOTO TEXT</b> Shift + Text /
[≡ ⊕ ]	<b>EQ SUBTITLE</b> Subtitle / EQ
[≡ i ]	<b>ANGLE INFO</b> Info / Angle
[≡ □ ]	<b>STEP - FREEZE</b> Pause / Step / Freeze
[≡ ◆ ]	<b>SIZE ZOOM</b> Zoom / Size
[≡ ? ]	<b>RDS AV INPUT</b> AV / Input / RDS
[≡ X ]	<b>CLEAR EXIT CANCEL</b> Exit / Cancel / Clear

Original	Substituto

