



|         | Original   | Substituto    |
|---------|------------|---------------|
|         | Power      | Power         |
|         | Open/Close | Eject         |
|         | 1          | 1             |
|         | 2          | 2             |
|         | 3          | 3             |
|         | 4          | 4             |
|         | 5          | 5             |
|         | 6          | 6             |
|         | 7          | 7             |
|         | 8          | 8             |
|         | 9          | 9             |
|         | 0          | 0             |
| ALARM1  | Alarm1     | Red           |
| ALARM2  | Alarm2     | Blue          |
| CLOCK   | Clock      | +  Shift + AV |
| SLEEP   | Sleep      | Sleep         |
| DISPLAY | Display    | Info          |

|  | Original    | Substituto |
|--|-------------|------------|
|  | Audio       | Dual       |
|  | Source      | AV         |
|  | Mute Snooze | Mute       |
|  | Vol+        | Vol +      |
|  | Vol-        | Vol -      |
|  | Up          | Up         |
|  | Down        | Down       |
|  | Right       | Right      |
|  | Left        | Left       |
|  | Enter       | Ok         |
|  | >> /Tu+     | >>         |
|  | <</Tu-      | <<         |
|  | Stop        | Stop       |
|  | Play        | Play       |
|  | Pause       | Pause      |
|  | Repeat      | Text       |
|  | Shuff       | Media      |



