







































































Original	Substituto	Original	Substituto
 Power	 Power	 Exit / Settings	 Exit
 Mute	 Mute	 YouTube	 Media
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	 Info	 Info
 4	 4	 EPG	 Guide
 5	 5	 PR+	 Ch +
 6	 6	 PR-	 Ch -
 7	 7	 Up	 Up
 8	 8	 Left	 Left
 9	 9	 OK	 Ok
 0	 0	 Right	 Right
 CH List	 List	 Down	 Down
 Return / Back	 Back	 Rec	 Rec
 Menu	 Menu	 Nicam / I/II	 Dual
 Source	 AV	 Text	 Text
 Home	 Smart	 AD / Sub-Page	 Subt





Original		Substituto		Original	Substituto
	FAV / Size		Pre Ch		
	Quick / Hold / Freeze	 + 	Shift + Stop		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Play/Pause / Index		Play		
	Play/Pause / Index		Pause		
	<< / Reveal		<<		
	>> / Mix		>>		
	Stop / Cancel		Stop		

