







































































Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	PP		Pre Ch
	I - LL		Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	--		Gui de
	P<P		Back
	Menu		Menu
	Info		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	P+		Ch +
	P-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Red/ Sound		Red
	Green/ Picture		Green
	Yellow/ Feature		Yellow
	Blue/ Install		Blue
	TV		TV/ R
	AV		AV
	[≡]		Text
	[ / ≡]		Media



