



Original	Substituto
	Power
	Mute
	PP
	I - I I
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	--
	P<P
	Menu

Original	Substituto
	Info
	Up
	Down
	Right
	Left
	P+
	P-
	Vol +
	Vol -
	Red/ Sound
	Green/ Picture
	Yellow/ Feature
	Blue/ Install
	TV
	AV
	[≡]
	[/ ≡]



