



Original	Substituto	Original	Substituto
Power	Power	3	3
Mute	Mute	4	4
Play	Play	5	5
[=]	Text	6	6
Pause/[/≡]	Pause	7	7
Stop/[≡+]	Stop	8	8
Rec/[≡◆]	Rec	9	9
<</[≡o]	<<	0	0
<</[≡i]	<<	Menu	Menu
>> /[≡?]	>>	Exit	Exit
>>/[≡x]	>>	Up	Up
Info	Info	Left	Left
EPG	Guide	OK	Ok
Subtitle	Subt	Right	Right
Audio	Dual	Down	Down
1	1	Back	Back
2	2	Home/Source	Smart





Original		Substituto		Original		Substituto	
SOURCE	Home/Source	TIMER AV	AV				
VOL+	Vol+	+ VOL	Vol +				
VOL-	Vol-	VOL -	Vol -				
LIST	List	DISC NAV LIST	List				
CH+	P+	+ CH	Ch +				
CH-	P-	CH -	Ch -				
[Red]	Red	A	Red				
[Green]	Green	B	Green				
[Yellow]	Yellow	C	Yellow				
[Blue]	Blue	D	Blue				
ZOOM	Zoom	ZOOM	Eject				
REC.LIST	Rec.List	SEARCH TV/R	TV/R				
FAV	FAV	FAV PRE-CH	Pre Ch				

