





































Original	Substituto
	Power
	Smart
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Info
	0
	Guide
	Netflix
	YouTube
	Google Play

Substituto	Original
	Power
	Smart / List
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Info / Angle
	0
	Guide / EPG / -/--
	Shift + Red / Netflix /
	Shift + Yellow / YouTube /
	Display / Media

Original	Substituto
	Shift + Blue / Prime
	Shift + Menu /
	Up
	Menu / Home
	Left
	OK
	Right
	Back / Return
	Down
	Exit / Cancel / Clear
	Vol+
	Mute / Dimmer
	CH+ / Page+
	Vol-
	AV / Input / RDS
	CH- / Page-
	Red / Netflix / Search

Substituto	Original
	Shift + Blue / Prime
	Shift + Menu /
	Up
	Menu / Home
	Left
	OK
	Right
	Back / Return
	Down
	Exit / Cancel / Clear
	Vol+
	Mute / Dimmer
	CH+ / Page+
	Vol-
	AV / Input / RDS
	CH- / Page-
	Red / Netflix / Search



