







































































Original	Substituto	Original	Substituto
 Standby / On	 Power	 USB Rec	 Rec
 Function	 List	 Display	 Info
 Open / Close	 Eject	 Vol+	 Vol +
 Home Media	 Media	 Vol-	 Vol -
 Karaoke	 Guide	 Mute	 Mute
 Mic Vol+	 Ch +	 Top Menu	 D. Menu
 Mic Vol-	 Ch -	 Menu / PopUp	 Menu
 Resolution	 Format	 Up	 Up
 Net Contents	 Shift + Media	 Left	 Left
 Key Lock	 Pre Ch	 Enter	 Ok
 Dimmer	 Shift + Mute	 Right	 Right
 Sleep	 Sleep	 Down	 Down
 Exit	 Exit	 Home Menu	 Smart
 Virtual 3D Sound	 3D	 Return	 Back
 Sound	 Dual	 Tools	 Options
 Sound Retriever	 Shift + Dual	 Continued	 Shift + Play
 CD/SACD	 AV	 Skip Search	 Shift + Right





Original		Substituto		Original		Substituto	
	REV		<<		6		6
	Play		Play		7		7
	FWD		>>		8		8
	I<< / <   / <		I<<		9		9
	Pause		Pause		0		0
	Stop		Stop		Clear		Shift + Exit
	>>  /  > /   >		>>		Program / Red		Red
	Audio		TV/R		Program / Red		Shift + Sleep
	Subtitle		Subt		RDS / Bookmark / Green		Green
	Angle		Shift + Format		PTY / Zoom /		Yellow
	Repeat		Text		PTY / Zoom /		Shift + Eject
	A-B		Shift + Text		Index / Blue		Blue
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

