




Original	Substituto	Original	Substituto
Power	Power	>>	>>
Input	AV	V.Menu	D. Menu
1	1	Mute	Mute
2	2	P+	Ch +
3	3	P+	Up
4	4	P-	Ch -
5	5	P-	Down
6	6	Vol+	Right
7	7	Vol+	Vol +
8	8	Vol-	Left
9	9	Vol-	Vol -
0	0	Menu	Menu
-/-	GUIDE	Display	Info
Pre CH	Pre Ch	P.STD	3D
<<	<<	Rec	Rec
Stop	Stop	Eject	Eject
Play	Play	Pause / P/S	Pause

Original	Substituto	Original	Substituto
Power	Power	>>	>>
Input	AV	V.Menu	D. Menu
1	1	Mute	Mute
2	2	P+	Ch +
3	3	P+	Up
4	4	P-	Ch -
5	5	P-	Down
6	6	Vol+	Right
7	7	Vol+	Vol +
8	8	Vol-	Left
9	9	Vol-	Vol -
0	0	Menu	Menu
-/-	GUIDE	Display	Info
Pre CH	Pre Ch	P.STD	3D
<<	<<	Rec	Rec
Stop	Stop	Eject	Eject
Play	Play	Pause / P/S	Pause





Original	Substituto	Original	Substituto
Crystal PB	TV/R		
TRK up	>>I		
TRK Down	I<<		
Index	List		
Memory	Ok		
Sleep	Sleep		
Lang.Sel	Dual		
Clear	Exit		
ShowView	Smart		
Mix	Shift + Text		
Text Size	Format		
Subpage	Subt		
TV/Text	Text		

Original	Substituto

